



OASIS Pressure & Fountain OneDoc

Specifications, Manuals, Accessories and more for the OASIS International Pressure and Fountain products.



Pressure Coolers - Wall Mounted

Series/Model

Versacooler II Series

PG8AC	Spec Sheet	Versacooler II Series Manual	Flow Adjustment	Parts Diagram
PG8ACSL	Spec Sheet	Versacooler II Series Manual	Flow Adjustment	Parts Diagram

This is the same as the P8AC series and is a replacement for the P8AM and PLF8WM/D/QA/QS series. Use part # 035421-001 bracket to use the same rough-in, however using this bracket will lower it below the ADA guidelines. If you need this ADA they will have to modify the unit or change the rough-in.

Versacooler II Series with VersaFilter

PGF8AC	Spec Sheet	Versacooler II Series Manual	Flow Adjustment	VersaFilter Manual
PGF8ACSL	Spec Sheet	Versacooler II Series Manual	Flow Adjustment	VersaFilter Manual

Versacooler II Vandal Resistant Series

PGV8AC	Spec Sheet	Versacooler II Series Manual	Parts Diagram
PGV8ACSL	Spec Sheet	Versacooler II Series Manual	Parts Diagram

Versafiller & Versacooler II Combos

PG8SBF	Spec Sheet	Versacooler II Series Manual	Flow Adjustment	Manual VersaFiller Manual	
PG8EBF	Spec Sheet	Versacooler II Series Manual	Flow Adjustment	Electronic VersaFiller Manual	Versafiller Sensor Setup

Pressure Coolers - Floor Series

Series/Model

Compact Floor Series

P3CP	Spec Sheet	Compact Floor Series Manual	Valve Adjustment	Parts Diagram
P5CP	Spec Sheet	Compact Floor Series Manual	Valve Adjustment	Parts Diagram
P10CP	Spec Sheet	Compact Floor Series Manual	Valve Adjustment	Parts Diagram

Sports Bottle Fillers

Series/Model

Sports Bottle Fillers

PWSBF	Spec Sheet	Manual VersaFiller Manual	Parts Diagram	
PWEBF	Spec Sheet	Electronic VersaFiller Manual	Versafiller Sensor Setup	Parts Diagram

The Retro Fit Sports Bottle Fillers can be installed on the OASIS P8AC and P8AM series Water Cooler. Optional Gaskets for Elkay and Sunroc models are available.

Accessories

VersaFilter Systems	Spec Sheet	VersaFilter Manual	Replacement Cartridge Manual
Part # 033926-001 Kit for VersaCooler Series. Part # 033926-002 Kit for other series. Part # 033879-001 Replacement cartridge.			
Green Filtration Systems - Quarter Turn	Spec Sheet	Green Filter Manual for P8AC	Green Filter Manual for Other
Part # 033926-003 Kit for VersaCoolers Series. Part # 033926-004 Kit for other series. Part # 034763-205 Replacement cartridge.			
Green Filtration Systems - In-Line	Spec Sheet	Green Filter In-Line Manual	
Part # 033926-005 Kit for In-Line. Part # 034763-215 Replacement Cartridge.			
Galaxy Filter System - Quarter Turn	Spec Sheet		
Part # 036930-001 Kit for VersaCooler Series. Part # 036930-002 Kit for other series. Part # 037116-101 Replacement cartridge.			
Galaxy Filter System - In-Line	Spec Sheet	Galaxy Filter In-Line Manual	
Part # 036930-003 Kit for In-Line. Part # 037116-101 Replacement cartridge.			
Apron for Versacooler II Split Level Water Coolers	Spec Sheet	Apron Manual	

Help Documents for Pressure Water Cooler and Fountain Products



- [Cross Referenced Parts - Use this to find parts that have been subbed or obsolete.](#)
- [Diagnosing Pressure Coolers - Maintaining and troubleshooting pressure water coolers](#)
- [Electric Eye Sensor - Adjustment and replacement info](#)
- [Haws Water Cooler Parts - Use this to determine parts and replacement](#)
- [OASIS RADII™ Modular Model Codes - Use this to determine parts and replacement](#)
- [OASIS Valves - Parts and adjustments](#)
- [P8AM Series - Maintaining and troubleshooting](#)
- [Pressurize P8AC Tank](#)
- [Quick Connect Fittings - Find your quick-connect fittings and how to use them](#)
- [SF-1895 Valve - Repair Kit, Strainer and replacement valves](#)

OASIS Pressure O & M for Current and Discontinued Models



Wall Mounted

EP8WM	Valve Adjustment	Parts Diagram	Valve Diagram
EP8WM-001	Valve Adjustment	Parts Diagram	Valve Diagram
EP8WM-AE	Valve Adjustment	Parts Diagram	Valve Diagram
EP8WM-D	Valve Adjustment	Parts Diagram	Valve Diagram
EP8WM-E	Valve Adjustment	Parts Diagram	Valve Diagram
EP8WM-EQ	Valve Adjustment	Parts Diagram	Valve Diagram
EP8WM-Q	Valve Adjustment	Parts Diagram	Valve Diagram
EP8WM-QA	Valve Adjustment	Parts Diagram	Valve Diagram
PAC-001	Versacooler	Valve Adjustment	Parts Diagram
P8AC-D300	Versacooler	Valve Adjustment	Parts Diagram

P8AC-H300	Versacooler	Valve Adjustment	Parts Diagram
P8ACSL-D300	Versacooler Split-Level	Valve Adjustment	Parts Diagram
P8ACSL-H310	Versacooler Split-Level	Valve Adjustment	Parts Diagram
PR8ACSL-D300		Valve Adjustment	Parts Diagram
PV8AC-D300			Parts Diagram

PAM	P8AM Series - Maintaining and troubleshooting		Parts Diagram
PAM-001	P8AM Series - Maintaining and troubleshooting		Parts Diagram
PAM-002	P8AM Series - Maintaining and troubleshooting		Parts Diagram
PAMS	P8AM Series - Maintaining and troubleshooting		Parts Diagram
PAMS-001	P8AM Series - Maintaining and troubleshooting		Parts Diagram
PAMS-002	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AM	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AM-100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AM-D100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AM-D300	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AM-D301	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AM-E100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMEE-E100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMS	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMS-100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMS-D100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMS-D300	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMS-D301	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMSL-100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMSL-D100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMSL-D300	P8AM Series - Maintaining and troubleshooting		Parts Diagram
P8AMSL-D301	P8AM Series - Maintaining and troubleshooting		Parts Diagram
PR8AM-D100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
PR8AMS-D100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
PR8AMSL-D100	P8AM Series - Maintaining and troubleshooting		Parts Diagram
PRV8AMSL-D300			Parts Diagram
PV8AMSL-D300			Parts Diagram

PLF8SKPE		Valve Adjustment	Parts Diagram	Valve Diagram
PLF8SKPE-100		Valve Adjustment	Parts Diagram	Valve Diagram
PLF8SKPE-101		Valve Adjustment	Parts Diagram	Valve Diagram
PLF8SKPE-D101		Valve Adjustment	Parts Diagram	Valve Diagram
PLF8SKPE-D102		Valve Adjustment	Parts Diagram	Valve Diagram
PLF8SKTP		Valve Adjustment	Parts Diagram	Valve Diagram
PLF8SKTP-100		Valve Adjustment	Parts Diagram	Valve Diagram
PLF8SKTP-101		Valve Adjustment	Parts Diagram	Valve Diagram
PLF8SKTP-D101		Valve Adjustment	Parts Diagram	Valve Diagram